Easy Wood Plans

www.easywoodplans.com

er agrees when its plan (the "Pian"): hoser has acquired the or construct the ject set out in the Plan) for his/her/its only and not for ol use. n of the Plan in whole ny means whatsoever

#7B, 2316-27Ave N.E. Calgary, Alberta Canada, T2E 7A7


Read all directions before beginning

Directions (4'x8' and 4'x4' sheds) Lay out your material on the workbench, as outlined materials layout for each component. Draw out al r The Handyman let for any willful lent use of this plan, lent use of the plan, lent tools used to Project or for any resulting therefrom."







- 3) Component B (Fig 2). Place the four pieces B1 between two pieces B2. The center of one of the two center pieces B1 is located 16 from the cutside edge of piece B2 and the other is located 16 from the center of this piece B1. Notil this assembly logether using sixteen 37 common nails, nating through the pieces B2 into the ends of the pieces B1, two nails per end. Place B3 on this frame so that piece B3 overlaps the edges of pieces B1 by 2° and overlaps to piece B2 by 1 1/2°. Notil piece B3 to the frame using forty 2° common nails six per piece B1 and five per piece B2. 4) Component C (Fig 3): Note C1, C2, C3 And C5 have an 8 degree cut in top end. C6 is mitered both ends. Before applying plywood to framing note how many components C you need. Components will have to be built as left and right hand walls. Notil through side of piece C4 to piece C1 ensuring that the bottom edges are even. Lay out pieces C1/C4, C2, C3 and C3 as shown see (Fig 3) between pieces C5 and C4 are flush with the autiside edges of pieces C6 and C7 and that the center of piece C2 is located 16 from the outside edge of pieces C3. Use eighteen 3° common nails, two each end of pieces C5, C3, C2 And C1 and two through C7 into the bottom of piece C4. Place piece C8 on top of the frame assembly so that the edges of C5 and C4 are flush with the edges of piece C6. Those piece C6 on top of the frame assembly so that the edges of C5 and C4 are flush with the edges of piece C6 to the frame using forty 2° common nails, two each in pieces C6 to the frame using forty 2° common nails, two each in pieces C8 to the frame using forty 2° common nails, two each, in pieces C6 to the frame using forty 2° common nails, two each, in pieces C6 to the frame using forty 2° common nails, two each, in pieces C6 to the frame using forty 2° common nails, two each, in pieces C6 to the frame using forty 2° common nails, two each, in pieces C6 to the frame using forty 2° common nails, two each, in pieces C6 to the Ŀ
- 5 Component D (door) (Fig. 4): Place the three pieces D1 between the two pieces D2 as shown and and with twelve 3 common nais; two per joint. The center piece D1 is 17 5/8" from the outside edge of either of the outside pieces D1. Place piece D3 on this frame, square, and noil to the frame using thirty two 2 common nails.





16° (406)













17 7/8"




(105) 4 1/8



COMPONENT B

(51)



STORACE SHEDS - 4x4, 4x8 Project #210

MATERIALS LIST (8°x4° SHED)

b. 3/4" roofing nails
 ete with mounting screws
 ete with mounting hardware

49 1/2"x4" floshing Seven sheet 5/8 plywood One sheet 5/8 plywood One 8/2x2 (1 1/2" Six 8/2x4 (1 1/2") one 8/2x6 (1 1/2")

Approx. 2 lbs. 3" common noils
Approx. 2 lbs. 2" common noils
Approx. 2 lbs. 2" common noils
or hinges complete with mounting screws
latch kit complete with mounting hardware Four half sheets 1/2" plywood

Twenty nine 8" 2x2" (11/2"x1 1/2")
Three 8" 2x4" (11/2"x3 1/2")
One 8" 2x4" (11/2"x5 1/2")
e One 8" 1x4" (3/4"x3.1/2")
One 8" 1x1" (3/4"x3.4")
Twenty four 3"x1/4" log boits (optional)

- 6) Component E (Fig 5): Note: This component is built for the 4'x4' shed only. If shed will be against another building E is not necessary. Place the four pieces E1 between two pieces E2. The center of one of the two center pieces E1 is located 14' from the outside edge of piece E1 and the other is located 16' from the center of this piece E1. Not assembly tagether using sixteen 3' common nails, noting through the pieces E2 into the ends of the pieces E1, two nails per end. Place E3 and overlaps one end of one pieces E1 two nails post end. Place E3 and overlaps one end of one pieces E2 by 1 1 2'' and 4 1/8'' at the bottom. Nail piece E3 to the frame using forty 2' common nails six per piece E1 and five per piece E2.
- 7) Component F (Floor) (Fig. 6): Lay out the four pieces F2 between the two pieces F1, with 16" between the centers of pieces F2 as shown in (Fig. 6). Noil through the F1's into the F2's using sistem 3" common nails, two into each end of pieces F2. Place piece F3 squarely on the F1/F2 assembly. Noil piece F3 to F1/F2 ossembly using twenty four 2" common nails, four into each F2 and eight into each F1.
- 8) Camponent G (Roaf) (Fig 7): Note if you are building 4*4* shed use other half of 5/8" sheet from floor for roaf. Layout four pieces G2 between two pieces G1 with 16" between the centers of pieces G2 as shown in (Fig 7). Noil through pieces G1 into pieces G2 using sixteen 3" cammon noils, two into each end of pieces G2. Diago sixteen of pieces G2 with 14" overhang on the side edge of one piece G1 and a 2" common noils.

4'x4' and 4'x8' shed assemblies

lote: A helper will be required for assembly.

Stand one piece C on end of one piece F so that the 4 1/8"overhang or piece C extends below the edge of and flush with the bottom edge of piece F. See exploded views (Figs 8 and 9) for the correct configuration.

4'x8' shed assembly

to build the 4'x8' shed refer to figure 8. From the underside noil or bolt two floor components F together using eight 3' common noils or three 3'x1/4' log bolts. Turn F assembly over, with a helper set wall C on floor F, noil C to F through C? with two 3' common noils. Be sure the 4 1/8' overlog of C covers side of F. Next place a wall 8 adjacent to C. Noil 8 to F. Next place A on end of 8. Noil bottom plates of A to F and noil inside corner of 8 to ents of walls A ond C. Use three 3' common noils into each wall. Looking from the outside, 8 should cover ends of walls A and C forming a finished corner. Take places H and indicate the first H with four 3' common noils. Stand other two walls C on ends of standing walls A and C with two noils each end. Noil second place H to beam pockets in A and C with two noils ether walls. One ends of standing walls A and C. Noil top edges of C through beam pocket into H with two 3' common noils. Stand other two walls C on ends of standing walls A and C. Noil top edges of C through beam pocket into H with two 3' common noils either side. Noil bottom plates of C to F. Using a scrap piece of plywood, noil across studs between C and C walls and A and C walls to reinforce wall joint. Stand last wall 8 in place and attach in a similar fashion to first wall 8. Noil each C down to wall plates and H with eight 3' common noils, was common noils. Wall each C down to wall plates and H with eight 3' rooking noils, six each side. Heng door D in A, you may have to plane a bevel in back edge of door so it will close evenly. Screen hinges to outside of door so door opens outwards, attach your door latch (according to the inside of shed, noiling it to A2 with six 2' common noils. Add decorative trim if desired and point with exterior point.

"x4" Shed Assembly

To build the 4x4 shed refer to figure 9. With a helper set wall C on floor F, noil C to F through C7 with two 3 common noils. Be sure the 4 1/8" overlap of C covers side of F. Next place a wall B adjacent to C. Noil B to F. Attach A on end of CB assembly. Noil bottom plates of A to F and noil inside corner studs of B to ends of walls A and C. Use three 3" common noils into each wall. Looking from the outside. B should cover ends of walls A and C forming a finished corner. Place of G in place with plywood overhanging walls ABC. If shad is free standing place with plywood overhanging walls ABC. If shad is free standing place with plywood overhanging walls ABC. If shad is free standing place with plywood overhanging sight 3" common noils. Tor noil heads and finish roof either with shingles, roofing tor or point. Noil component J to high side of roof with four 2" common noils. J acts on overhang on side E. If your building leans up against another building substitute piece H for wall E and use flashing against existing building to replace J. Hang door D in A, you may hove to plane a bevel in back eagle of door so it will close easily. Screw hinges to outside of door so door opens autwords, attach your door latch (according to manufacturer's instructions). Use a plywood trimming for doorstop on the inside of shed, noting it to A2 with six 2" common noils. Add decordive trim if desired and point with

2700

COMPONENT H

COMPONENT J COMPONENT K

1 x 4 solid and 1 x 1 solid

STORAGE SHEDS - 4x4, 4x8 Project #210 (Side B)

Table Saw and Jigsaw Pencil and Measuring Tope Power or Hand Drill 1/16*, 1/8*, 3/8* drill bits Hammer and Screwdrivers Square and Noil Set. Plane and Wood Chisels Paint Brush and Putty Knife

