Procedure 2) - See Figure 3

Slort the project by building the seat assembly first. Follow the step by step procedure as outlined in Figure 3. If you are using soft wood such as cedar or redwood, and drywall screws, you should not have to pre-drill the wood, however the use of fir may require pre-drilling. If so, then a 5/64 "artill will work for drywall screws, or use a 3/32" for #8 screws, and 7/64" for #10 screws.

TIP: The use of a 'C' clamp will help in holding the pieces of wood together when inserting the screes. This assures the proper location is maintained and a light filting joint will result.

In step #1 & 2, keep all pieces flush to the lop and front sides. In step #3 & 4 foster the scale pieces A & K with one 1-1/2" screw at each each to step #5 (esten the completed sect back to the base frame with only one 1-1/2" screw in each side (only one screw will allow you to objust the angle to match the position of the orm eats in step #9, you can odd wo make the position of the insert them from the inside into pieces B. Try to manifolm the 100 degree ongle of the seat back. This will be reinforced by the arm rests in step #9.

cedure 3) - See Figure 4

As laid out in step \$6, altoch the arm rests £ & F to the tops of the legs pieces H. Make sure to reverse £ & F so you have a left and right assembly. The addition of a temporary brace in step \$7 may assist in attaching the leg assembly to the seat base. Once the arm rests are fostered, the legs may be fastered to the seat base as indicated, use two 2-1/2 screws for each leg, driven in from the outside face of H (\$15ep B). Since you only installed one screw in step \$5, the seat back will rotate somewhat so that you may align the arm rest with the back side of piece D (\$1ep b). Use two 1-1/2" screws through D into £ & F from the inside of the back.

cedure 4)

If you haven't done so, now you are ready to oil or stain the project. First make sure the seats and arms are sanded smooth so your friends don't go home with a sliver where they don't want one. Happy sunning —





